



AMERICAN DELUXE TELECASTER[®], MN, ASH, 0101702






AMERICAN DELUXE TELECASTER[®], MN, ASH, 0101702










WIRING DIAGRAM












SWITCH & CONTROL FUNCTION



	PICKUP IS ON
	PICKUP IS OFF
<i>A</i>	PICKUP (NECK)
<i>B</i>	PICKUP (BRIDGE)

3 WAY SW POSITIONS, S-1 SWITCH UP			
			POSITION
			← NECK (A)
			← BRIDGE (B)
NECK ONLY	NECK & BRIDGE PARALLEL CONNECTION	BRIDGE ONLY	CONNECTION

3 WAY SW POSITIONS, S-1 SWITCH DOWN			
			POSITION
			← NECK (A)
			← BRIDGE (B)
NECK ONLY	NECK & BRIDGE SERIES CONNECTION	BRIDGE ONLY	CONNECTION