

# CLASSIC PLAYER BAJA TELECASTER®, 014-1502

## WIRING DIAGRAM

